

4818757610-04

**EasyPact™**

**Extended Rotary Handle**

Commande rotative prolongée

Manija rotativa extendida

Manopia rotativa prolongada


The manufacturer assumes no responsibility for damage resulting from the non-application or incorrect application of the instructions provided herein.

Le non respect des indications de la présente notice ne saurait engager la responsabilité du constructeur.


El fabricante no se responsabiliza de los daños originados como resultado de la falta de aplicación o aplicación incorrecta de las presentes instrucciones.

O fabricante declinará toda e qualquer responsabilidade pelo resultado do não cumprimento das indicações constantes do presente manual de instruções.

**EZAROTE**




Schneider Electric







**WARNING**


Hazardous voltage can shock, burn or cause death. Disconnect power from source before installing, modifying or servicing.




mm




ON




OFF




Tripped




Reset



ON + RELEASE



OFF



ON

